


SEEN SAFETY



IRIS 860 Setup Dongle

PN SI-138

The IRIS 860 Setup Dongle* allows you to change the IRIS 860 sensor settings.



How to change the sensor settings:

Download and install the SEEN IRIS 860 setup app on a smartphone or tablet. Launch the app and follow the on-screen instructions.



Note: The double sided adhesive tape on the dongle can be used to attach the USB battery pack.

FREE SUPPORT

SEEN are here to help. If you have a question or would like support, please email support@seensafety.com.

* This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

